


Dimension Guide


Wine cabinet

Model:

EWS830FCB-X



When positioned in a corner area, spacing of at 195mm+10mm on the hinge side will allow the doors to open enough to enable the removal of bins and shelves.



注意: 頂部空間須預留200mm

酒櫃機體尺寸	酒櫃含門寬度 (W)	酒櫃含門深度 (D)	酒櫃含門高度 (H)	酒櫃不含門寬度 (W1)	酒櫃不含門高度 (H1)	酒櫃不含門深度 (D1)	酒櫃開門深度 (D2)
EWS830FCB-X	483	577	832	493	831	540	1034

Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions.

© 2025 Electrolux S.E.A PTE. LTD. ELX_DIM_EWS830FCB-X_Jan25